

EK 315 Instructions for Teryx Side Door Enclosure



Toll Free 1-877-444-4147
www.Jstrongindustries.com

Parts List:

- 1-left sideview enclosure
- 1-right sideview enclosure
- 1-Roll of Hook Velcro

Tools Needed:

- Scissors or Knife
- Phillips head screwdriver

Installation Instructions:

Step 1:

Lay side panels on a clean, dry surface and allow them to warm up to room temperature to produce a tight fit.

Step 2

Align and attach the side panel to the top roll bar as shown in Figure 1. Figure 2a & 2b shows you how the Velcro strap wraps around the bar.

Step 3:

Clip Jstraps in front and rear fender wells as shown in Figure 3

Step 4:

Install adhesive back Velcro along the roll bar and align with the loop side as shown in Figure 4

Step 5:

Installation is complete. Your Teryx Enclosure should look like figure 5

Repeat all 4 steps for the other doors side enclosure

*Remove rear dust guard and zip out windows completely prior to transporting on highways were speeds may exceed 55 mph

*Your new rear dust guard and side enclosure is made of the highest quality clear flexible acrylic. It will, however; scratch if not handled correctly.

