

Instructions for JStrong Teryx Rear Dust Panel EK 314

Parts List:

1-4' J channel
1-Rear Acrylic Clear view Dust panel
2yds Velcro
10 Screws

Tools Required

Scissors & Phillips Screwdriver



Toll Free 1-877-444-4147
www.Jstrongindustries.com

Installation Instructions:

Step 1

From rear of the Teryx test fit the rear dust guard. Strap the sides as shown in (fig 1)

Step 2

Attach plastic J channel into the top J channel that is mounted on the top of the rear dust guard as shown in (Fig 2) * if installing with a JStrong Top attach Top J channel to JStrong Top as shown in (fig 3)

Step 3

Before supplied Velcro can be installed, you must clean both the corresponding roll bars with alcohol.

Step 4

Install supplied Velcro on each side of the rear roll cage bars to corresponding Velcro mate on rear dust panel.

Step 5

Install additional Velcro as needed across the bottom of the rear panel.

Your installation is now complete!

